

# GEWA Digital Piano PP-3

## Update Guide

This manual will help you to update your GEWA digital piano PP-3.  
You will need a USB stick and the appropriate firmware to complete this update.

### Update / Installation

#### Step 1

Connect your PP-3 via a USB cable from the USB to host port to your PC.

#### Step 2

Push and hold down the two keys "lowest a and c-sharp" and switch on the digital piano to enter the update mode. (see picture)



### **Step 3**

Start the PP-3 Updater on your PC (.exe for Windows PCs; .app for Mac OS).

### **Step 4**

Select the device "PP-3\_Boot(RPC)" and click "Start Program".

### **Step 5**

After successful installing the update, please restart your instrument. Long-Press the Power-Button to switch Off the instrument.